



Pioneer Water Tanks Preventative Maintenance/ Warranty Compliance Program

All packages include:

- Inspect tank perimeter is clear of vegetation & debris - *treat with herbicide.*
- Check aggregate around the tank.
- Check ladder and bracket are safe and structural integrity has not been compromised.
- Inspect roof of tank is clean and free of debris- *clean roof with blower and/ or hose as required.*
- Check hatch is in good working condition & ideally locked.
- Inspect leaf basket condition- *clean roof basket as required.*
- Ensure there is nothing foreign in tank – *i.e. frogs, rats, snakes, leaves.*
- Ensure tank has at least the minimum amount of water.
- Rain first flush diverter (if fitted) - *unscrew cap & clean out collected debris and replace cap.*
- Check and inspect for pest or vermin activity – *i.e. burrowing or damage around the tank.*
- Check sacrificial magnesium anodes - *replace if/ when required (every 5 years).*
- Check tank walls (external) – *clean.*
- Check poly & brass valve tank fittings.
- Check internal tank condition - *Does tank need cleaning? What is tank condition?*
- Check level indicator operation.
- Check condition of rain saver caps, water saver & gutters. – *clean.*

Rural Tanks	Zone 1 0 – 50km	Zone 2 50 – 100km	Zone 3 100 – 200km	Zone 4 200km +
3 Monthly Inspection	\$198.00 + GST	\$243.00 + GST	\$376.00 + GST	\$545.00 + GST
6 Monthly Inspection	\$253.00 + GST	\$298.00 +GST	\$431.00 +GST	\$630.00 + GST
12 Monthly Inspection	\$308.00 + GST	\$353.00 +GST	\$486.00 +GST	\$685.00 + GST